

## How to change country for app installation

[Change your Apple ID country or region]


1. Open the Settings tab.
2. Tap your username, then tap “Media & Purchases.”
3. Tap ‘View Account’ (you may be prompted to log in)
4. Tap ‘Country/Region’.

---


[Change Google Play country]

1. Open the Google Play Store app
2. Tap your profile icon in the top right corner.
3. Tap Settings › General › Accounts & Devices Preferences › Country & Profiles.
4. Tap the country you want to add the account to.
5. Follow the on-screen instructions to add a payment method to your country.


Connect your phone to your **2.4GHz** router.  
(All routers support 2.4GHz and 5GHz simultaneously.)




Touch + in the upper right corner.




Specifies the name of the installation region and its current location.



Specify the room name and device name.




Touch and hold the power button until you hear a beep, then touch the 'Next' button when the **white LED** flashes.



# Enter the name and password of the wireless router accurately, case sensitive.

(If entered incorrectly, "DEVICE OFFLINE" will be displayed on the main screen.)


Touch 'Go to Wi-Fi selection screen'






# Touch 'ElecQUA\_XXXXXXXXXX'

Since you are not connected to the Internet yet, you will see a message like "You are not connected to the Internet."




‘Switch to another connectable network’, etc.  
When prompted, choose Keep.


A 'No Internet Connection' message is normal.



Return to the ElecQUA application and touch Next.




Please wait for a while until the device is registered to the server.





## registration success

In case of successful registration, it is displayed in green, and in case of registration failure, it is displayed in gray.




# registration failed

- ① Check if the mobile phone is connected to a 2.4Ghz router.
- ② Check if you have entered the wireless router name and password correctly, then register again.




**When registration is successful, it measures the water temperature for 10 seconds and operates automatically.**

All settings are stored on the device and will continue to work with the original settings even after a power outage.



**Go to the device settings window and swipe down to request the latest status of your device.**


(The device updates the latest status once every 5 minutes.)






**Touch Water temperature sensor calibration to enter the current water temperature in the water tank.**

(It is recommended to calibrate after checking the latest status.)



# Activate the child lock as the touch sensor may be activated by water droplets or static electricity.

(Kids Lock is released when the power is reconnected.)



When controlling on/off with an application, it takes about 2~3 seconds to check the operation status of the device.

